





Share a device between different accounts

Once you have scanned a device (NVR) you CANNOT scan it again, it is now registered to your account. You can view on multiple devices simply by using the same login username and password you created when you first signed up to the Dorani IP Viewer APP. Alternatively, you can share the device to a different account if you want to set the time they can view or set restricted access to certain features. This is also a tool used by our technical support team to remotely login to your system if required. For information on this please feel free to contact us at support@dorani.com.au




STEP 1

Open the Dorani IP Viewer APP on your device and select the **MENU** button




STEP 2

Select **DEVICES**
(account username is written next to the face icon)




STEP 3

Select the **DEVICE OPTIONS** button on the device you want to share to bring up the menu




STEP 4

Select **SHARE** from the device menu



STEP 5

Choose what to share. You can select a single camera or the whole NVR (all cameras)



STEP 6:

Enter the account to share to (email or username)

Select how long you want to share the device for

Select "By function" or "Role".

By Function: choose what privileges you want to share from the icon list below.

By Role : Select the user

IMPORTANT

If you are sharing to the 'doranisupport' account, you **MUST** choose 'role' as the type and select 'admin' as the user.

Once complete, tap 'Share' at the bottom of the screen. If done correctly

Shared successfully.

Will appear at the bottom of the screen.